


RESIDENTIAL BEACON



THE INFORMATION CONTAINED IN THIS DRAWING IS SOLE PROPERTY OF GLOBAL FLAG UNLIMITED. ANY REPRODUCTION IN PART OR IN WHOLE WITHOUT WRITTEN PERMISSION OF THE FLAG			
COMPANY, INC. IS PROHIBITED. Global Flag Unlimited			
DRAWN RDW	10-19-06	Global Glag Unlimited FLAGPOLE BEACON U.S.Patent #7.275.495	
Revised KBG	09/04/15		
DESIGNER DOW	10-19-06	SIZE	DWG NUMBER
APPROVED MWL	09/04/15	A	EXT-359
SCALE	None	REV -	SHEET 1 OF 1

Residential Beacons

Details

- Single light
- 110 Volt; LED bulbs
- 5" Gold or Silver ball
- 359 degree revolving truck
- Minimum 5' extra cable
- Rubber coated and direct buried wire

Installation Instructions

- Follow PVC ground sleeve instructions.
- Attach Beacon to top section of pole while threading cable through center of pole.
- Secure Beacon by tightening all three setscrews evenly.
- Continue threading cable through each section until you reach the last section.
- Connect cable to cable, matching the colors. (Always connect male to female.)
- Attach last sections together, pushing excess cable down into the bottom section.
- If you have an optional flash collar, slide it on now.
- Attach cleat with two screws provided.
- Thread rope halyard through truck and tie each snap into place using overhand knot.
- Stand pole up, following enclosed installation instructions.

<u>Changing Bulbs</u>

- · Disconnect power from pole.
- Loosen retainer clips using phillips head screwdriver while holding bulb in place.
- Carefully remove bulb from socket (CAUTION: glass can break causing injury).
- Tighten retainer clips to secure bulb in its place UPDATED 9/23/22